

Samsung S3370 Flash guide.

15 April 2010.

www.samsung-firmware.webs.com

What to do first:

- 1) Save everything.
- 2) Take out SIM card.
- 3) Take out Micro SD.

What you need:

- 1) Firmware.
- 2) Flash program.
- 3) Flash cable (Original USB cable)
- 4) Your phone: S3370.

Lets start.

- 1) Start with a hard rest for safety. (code *2767*3855#)
- 2) Check your firmware (Code *#1234#)
- 3) Check our firmware list and download a firmware you want. (We use S3370XEJD2)
- 4) Download the flash program. (Multiloader v5.63!) (Find this on our S3370 page)
- 5) Unrar the firmware.
- 6) Unrar the program.
- 7) Into the Firmware you will see three files. (Our ReadMe, CSC and CODE)
- 8) Open the multiloader.
- 9) Set a check by Boot Change.
- 10) Click on Boot and go to the Boot file and click.
- 11) Set in multiloader a check by All Download.
- 12) click on Amss and go to the file.
- 13) Do the same by Rsrc1, Rsrc2, Factory FS, CSC, SHP SPP and PFS.
- 14) NOTE select by RSRC2 always the LOW version!
- 15) NOTE check FFS and PFS on the same region. (We use SER)
- 16) Take you USB cable.
- 17) Take your phone.
- 18) Put your phone in Download MODE.(Sound Key Down + Camera + Power On) (Make sure your phone is out before)
- 19) You will seen now: DOWNLOAD MODE or ALL DOWNLOAD or BOOT change.
- 20) Take your USB cable and put him in your Phone and PC.
- 21) Let the PC first install the drivers.
- 22) Go to multiloader and click on Port Search.
- 23) Wait 20 sec.
- 24) If he is ready click on Download.
- 25) Don't do anything now. (After the update he will be on agian.)
- 26) Congratulations, Your update is fine for 100%
- 27) End the flash thing with a hard reset. (code *2767*3855#)
- 28) If your phone start again wait and shut him down normally.
- 29) Put you Simcard and your micro SD back in.
- 30) Your phone have now the last firmware and is 100% up to date.

Try this guide on your own risk.

www.samsung-firmware.webs.com

This is our example of the program fully loaded.

