

Repair Movies

- mechanical –



Xperia™ XZ2
H8216, H8276, H8266, H8296

CONTENTS

1	Disassembly Movie	3
1.1	Disassembly	3
1.2	Removing Adhesive Battery エラー! ブックマークが定義されていませ ん。	
2	Reassembly Movie	4
2.1	Reassembly	4
3	Revision History	5

To view the embedded repair movies in this document, video play back application such as Media Player is required.

***If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow.
In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.***

1 Disassembly Movie

1.1 Disassembly

The disassembly is done in the following order:

- | | |
|---------------------|---------------------|
| 1. Cap Combo | 14. PBA ANT 2 |
| 2. Display | 15. FPC USB |
| 3. Battery | 16. FPC Key |
| 4. Sub Camera | 17. Bottom Spk Box |
| 5. Main Camera | 18. Holder Ant Main |
| 6. Main PBA | 19. WLC |
| 7. Sub PBA | 20. NFC |
| 8. Top Spk | 21. FP Sensor |
| 9. FPC Top(Mic 2) | 22. Cover Main |
| 10. Vibrator LRA | |
| 11. Holder Ant Gnd | |
| 12. PBA ANT 1 | |
| 13. FPC Relay(Mic1) | |

Double click the icon to play back the movie. →



2 Reassembly Movie

2.1 Reassembly

The reassembly is done in the following order:

- | | |
|--------------------|--------------------|
| Cover Main | 15. Main Camera |
| 1. FP Sensor | 16. Sub Camera |
| 2.NFC | 17. Holder Ant Gnd |
| 3. WLC | 18. Vibrator LRA |
| 4. FPC Key | 19. Battery |
| 5. Holder Ant Main | 20. Display |
| 6. Bottom Spk Box | 21. Cap Combo |
| 7. FPC Relay(Mic1) | |
| 8. FPC USB | |
| 9. PBA ANT 2 | |
| 10.PBA ANT 1 | |
| 11. FPC Top(Mic 2) | |
| 12. Top Spk | |
| 13. Sub PBA | |

Double click the icon to play back the movie. →



3 Revision History

Rev.	Date	Changes / Comments
1	2018-Mar-9	Initial release