


SONY

make.believe

Repair Movies

- mechanical -



Xperia™ SP
C5303/C5302/C5306/M35h/M35c/M35t

CONTENTS

1 Movies 3

1.1 Disassembly 3

1.2 Reassembly 3

2 Revision History 4

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.

For general information about repair movies, refer to 1220-1333: Generic Repair Manual - mechanical

The only difference of the disassembly/reassembly between C5303/C5302/C5306/M35h and M35c/M35t is the actions of disassembly/reassembly of the Camera Key FPC which is shown in the Working Instruction (1270-2228).

1 Movies


1.1 Disassembly

- Cover Battery Assy
- Ant Rear Cover Assy
- Main PBA
- Speaker Box Assy
- Carrier LCD Frame Assy (a) & Touch Front Cover Assy (b)



1.2 Reassembly

- Touch Front Cover Assy (a) & Carrier LCD Frame Assy (b)
- Speaker Box Assy
- Main PBA
- Ant Rear Cover Assy
- Cover Battery Assy



2 Revision History

Rev.	Date	Changes / Comments
1	2013-Apr-19	Initial release
2	2013-May-2	Improvements for better viewing(method not change).
3	2013-May-16	Add note about M35c.
4	2013-Sept-09	Add note about M35t.
5	2014-Feb-18	Change the torque info since 1281-0042 Screw Len:3.8 Diam:1.4 is added.