

## Part List

- mechanical -



*Xperia Z3*  
*D6633, L55t, L55u, D6683*

CONTENTS

1 Part List ..... 3

2 Revision History ..... 12

## 1 Part List



The following parts are available for order in 'E-star'.

















The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

















Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

















RLC, Reversed Logistic Classification column for replaced part handling, See the Spare Part Handling chapter in Mechanical/Generic Repair Manual 1220-1333.

Designation	Part No.	RL C	Part	Location
Adhesive Battery Front	1282-1899	C		
Adhesive Charge FPC	1282-3276	C		
Charge FPC	1280-6834	C		
Sheet Sub PBA	1290-0790	C		
Adhesive Rear Panel	1288-3738	C		
Adhesive Relay FPC B	1286-1191	C		
Adhesive Relay FPC A	1286-1179	C		

Designation	Part No.	RL C	Part	Location
Adhesive WP Audio Jack	1282-1919	C		
Antenna BT + WLAN	1285-3560	C		
Audio Jack	1285-7766	C		
Cap SIM Cap SIM Black Cap SIM Copper Cap SIM White	1285-2985 1285-8077 1290-4819	C		
Cap USB Cap USB Black Cap USB Copper Cap USB White	1285-3014 1285-8082 1290-4817	C		
Cover Holder -A	1285-3559	C		
Cushion 10pin BB speaker	1286-1246	C		
Cushion Audio Jack FPC BtB	1286-7043	C		
















Designation	Part No.	RL C	Part	Location
Cushion Battery	1282-1898	C		
Cushion Battery FPC BtB	1282-4139	C		
Cushion Camera BtB	1282-1901	C		
Cushion Chat Camera	1282-1927	C		
Cushion Rear Panel	1289-4962	C		
Cushion Relay FPC bottom BtB	1286-7044	C		
Cushion Relay FPC BtB	1282-4137	C		
Embedded Battery	1281-2461	B		

Designation	Part No.	RL C	Part	Location
Film Display BtB	1286-6445	C		
Film for TP FPC	1286-1276	C		
<u>Front Assy</u> Front Assy Black Front Assy Copper Front Assy White	1288-5869 1288-5871 1288-5870	A		
Gasket conductive USB	1286-7041	C		
Gasket speaker rubber	1285-3561	C		
Gore Sheet(1st mic)	1282-1787	C		
Grill Receiver Black	1282-1929	C		
Holder key volume	1285-7769	C		





Designation	Part No.	RL C	Part	Location
Holder Mic sub assembly	1282-1878	C		
Holder Receiver sub assembly	1282-1875	C		
Holder Speaker sub assembly	1285-3542	C		
<u>Label tray</u> Label tray D6633 Label tray L55u Label tray D6683	1285-7652 1290-3312 1296-0217	C		
<u>Core Unit Label</u> Core Unit Label D6633 L55u D6683	1285-8695	C		
<u>Label Guide</u> Label Guide D6633 L55u,D6683	1285-7661	C		
<u>Label tray</u> Label tray L55t	1290-3313	C		
<u>Core Unit Label</u> Core Unit Label L55t	1290-5654	C		

Designation	Part No.	RL C	Part	Location
<u>Label Guide</u> Label Guide L55t	1290-3315	C		
Liquid indicator	1275-3307	C		
Loudspeaker B	1286-7114	C		
<u>Magnetic connector</u> Magnetic connector Black Magnetic connector White	1281-9617 1281-9655	C		
Main Antenna	1285-3552	C		
Main Camera	1280-7695	B		
Plate holder speaker	1285-3551	C		
<u>Rear Panel</u> Rear Panel Black,L55t Rear Panel Black,L55u,D6633,D6683 Rear Panel Copper,L55t Rear Panel Copper,L55u,D6633,D6683 Rear Panel White,L55t Rear Panel White,L55u,D6633,D6683	1288-8875 1288-8892 1288-8881 1288-8898 1288-8880 1288-8896	B		



Designation	Part No.	RL C	Part	Location
<u>Relay FPC</u> Relay FPC PBA	1285-7754	B		
RF cable	1281-9925	C		
Screw M14x3.3	1285-7670	C		
Sheet ACO L	1286-1249	C		
Sheet ACO R	1286-1254	C		
Sheet Chat Camera	1288-0301	C		
Shield Main Camera	1285-3562	C		
SIM Tray(L55u, D6633, D6683)	1285-0492	C		

Designation	Part No.	RL C	Part	Location
SIM Tray(L55t only)	1285-0492	C		
Dummy SIM assy (L55t only)	1288-7849	C		
Sub Antenna	1281-7580	C		
Sub Camera	1280-7656	C		
Sub PBA-A	1286-8355	C		
Sub PBA-B	1285-7780	C		
Cushion MIC	1290-5371	C		
Lightguide 3 LED Lightguide 3 LED White Note: (For white color Phone only)	1291-7248	C		

Designation	Part No.	RL C	Part	Location
Sheet Battery Long	1292-6858	C		
Sheet Battery Short	1292-7293	C		

## 2 Revision History

Rev.	Date	Changes / Comments					
1	2014-09-12	Initial release					
2	2014-10-30	Add Lightguide 3 LED White (1291-7248). Delete Sheet sub ANT(1290-3567). Changes P/N of Adhesive Relay FPC A to 1286-1179.					
3	2014-11-05	Update comments of Lightguide 3 LED White (1291-7248) for white color phone only.					
4	2014-11-27	Add two new parts: <table><tr><td>1292-6858</td><td>Sheet Battery Long</td></tr><tr><td>1292-7293</td><td>Sheet Battery Short</td></tr></table>		1292-6858	Sheet Battery Long	1292-7293	Sheet Battery Short
1292-6858	Sheet Battery Long						
1292-7293	Sheet Battery Short						
5	2014-12-04	Update 1286-1276 location photo					
6	2014-12-22	Add new part: 1287-3092					
7	2014-12-24	ET982 Screen Protector 1287-3092 temporally removed					
8	2015-04-08	Add D6683					