

## Repair Movies

- mechanical -



*Xperia™ Z5 Compact*  
*E5803, E5823*

CONTENTS

1 Movies ..... 3

1.1 Disassembly ..... 3

1.2 Reassembly ..... 3

2 Revision History ..... 4

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.

For general information about repair movies, refer to 1220-1333: Generic Repair Manual - mechanical

## 1 Movies

### 1.1 Disassembly

The disassembly is done in the following order:


1. SIM Tray
2. Panel Back
3. Label Tray
4. Ant Main Flex Gina
5. Cover Rear Sub Assy
6. Speaker holder assy
7. Main Camera (a) & Chat Camera (b)
8. Carrier Holder Key
9. Front Assy
10. Battery Assy
11. FPC Assembly JK (a) & Sheet Insulative DTV Tuner (b)
12. FPC Assembly Flash
13. FPC Assembly Bottom (a) & Sheet Insulative NFC (b)
14. Main PBA Assy



### 1.2 Reassembly

The reassembly is done in the following order:

1. Main PBA Assy
2. FPC Assembly Bottom (a) & Sheet Insulative NFC (b)
3. FPC Assembly Flash
4. FPC Assembly JK (a) & Sheet Insulative DTV Tuner (b)
5. Front Assy
6. Carrier Holder Key
7. Battery Assy
8. Main Camera (a) & Chat Camera (b)
9. Speaker holder assy
10. Cover Rear Sub Assy
11. Ant Main Flex Gina
12. Label Tray
13. Panel Back
14. SIM Tray



## 2 Revision History

Rev.	Date	Changes / Comments
1	2015-Sep-07	Release
2	2015-Sep-17	Update screw torques